
Exercise 1.16:



Stamp - mechanism	
Create the double crank mechanism with the given coordinates by using SAM. Now set the INPUT MOTION so that the rubber stamp CD moves 180° counter-clockwise (turning left) and after that directly 180° clockwise (turning right).	A _o (0/0) A (20/0) B _o (40/0) B (60/0) C (60/-20) D (80/-20)